



Easy Manual (for the operator)
Cream whippers models CW 2 - CW 5

IMPORTANT RULES


NEVER:

! ADDING SUGAR IN CRISTALS, ONLY LIQUID SUGAR.

! DISASSEMBLE THE PUMP FOR CLEANING.

Machine's operation:

- | | |
|----------------------------------|--|
| 1. ON/OFF button | For switching the machine on and off. |
| 1a. Power LED | Light indicates that the machine is powered up. |
| 2. Digital display | Displays the functions and data set. |
| 3. "P1 Dispensing" button | When pressing this button, cream is dispensed to about 1 oz., if active, signal led (3a) is on |
| 4. "P2 Dispensing" button | When pressing this button, cream is dispensed to about 3 oz., if active, signal led (4a) is on. |
| 5. "P3 Dispensing" button | Button for the dispensing of the whipped cream:
- with "PU" parameter, the dispensing will go on until the "P3 Dispensing" button is released, if active signal led (4a) is on;
- with "CO" parameter, the dispensing will go on up to the following pressing of the "P3 Dispensing", if active signal led (4a) is on. |



Reassembling of the labyrinth, tube and tap:

Reassembling of the labyrinth, tube and tap.

- (M1) Insert the labyrinth into the hole on the front panel. Insert the end of the labyrinth with the two O-rings in the pump cover.
- (M2) Insert the key in the hole of the pump cover.
- (M3) Insert the tube with the tap in the hole on the front panel.
- (M4) Rotate the tap anticlockwise to block it on the front panel.





Setting Air Regulator

- Rotate knob clockwise until the air regulator is closed (position 0).
- Rotate knob counterclockwise to necessary value. Standard position is between 2 - 3.




Operation:

- (D1) Pour cream into the mix container up to half of its capacity.
- (D2) Press the "P1 DISPENSING" button to dispensed to about 1 oz.
- (D4) Press the "DISPENSING" button again to stop the continuous functioning.




E Cleaning process

Having pressed the PROGRAMMING / ADJUSTMENT + button , the P3 code flashes on the digital display.

Setting the continuous dispensing (Co). Maintain the dispensing active until the washing solution mix contained in the mix container is used up.

- (E1) Pour drinking water at ambient temperature into the mix container up to half of its capacity.
- (E2) Place a suitable mix container under the dispensing tap .
- (E3) Press the "DISPENSING" button to drain the rinsing water in the mix container into the appropriate container placed under the dispensing tap .
- (E4) Press the "DISPENSING" button again to stop the continuous functioning.



IMPORTANT DETAILS (cleaning process)

- (F1) Turn the air-regulating knob counterclockwise and remove it vertically.
- (F2) Pull the valve holder out vertically.
- (F3) Take out the regulating valve from the valve-holder and rinse it under the water.

